

Cafe Doors

Before You Start

Congratulations! You've just purchased a top quality all wood Pineroft product. Pineroft Café doors are easy to install and can be stained and varnished to highlight their beautiful woodgrain or painted to accent any décor.

Staining and Varnishing

- 1 - Apply a high-quality stain of your choice. Apply according to stain label instructions.
- 2 - Sand if the wood seems "fuzzy" or "rough" with a medium-to-fine grade sandpaper or steel wool.
- 3 - Apply adequate coats of clear sealer or varnish.

Painting

- 1 - Prime all exposed surfaces with a high-quality primer according to paint label instructions.
- 2 - Allow to dry as specified.
- 3 - Sand if necessary as in step 2, above.
- 4 - Apply adequate finish coat/coats of a quality interior paint.

Café Door Installation

Tools Required:

- #2 Phillips screw driver
- Drill
- Drill Bits
- Tape Measure
- Pencil
- Level

Position of café door at door opening will vary, based on personal preference. A measurement of 18" to 24" from the finished floor to the bottom edge of finished doors is recommended. Each door is positioned with the high end of decorative arch towards the center of door opening (see door position in diagram).

Before installation, locate center of door jamb and, using a level, lightly pencil a vertical guide line at least 43" long.

- 1 - Mount top pivot to top of door, 1/4" from edge of finished door.
- 2 - Mount bottom pivot (A) to bottom of door, 1/4" from edge of finished door.
- 3 - Mount bottom pivot (B) to door jamb at the desired height. Use the center guide line to center the pivot on the jamb. Set door into bottom pivot.
- 4 - Mount top hinge on jamb center line, allowing 3/8" of height between top pivot pin section and pivot post. (See diagram, step #4). This compensates for the rise of the café door when swinging into an open position.