

GroundMaster Post System

Before You Start

Check with your Utility Company BEFORE installing this product to locate any underground utilities.

- 1 - Locate installation position and check for proper alignment.
- 2 - Place a short 4x4 post, about 2" longer than collar depth, into post system collar.
- 3 - Using a sledge hammer, strike the short 4x4 post.
- 4 - After a few strokes, check vertical alignment with a level.
- 5 - Continue striking the post until collar is flush with the ground.
- 6 - Remove short post. Place the actual post into the collar.
- 7 - Check to ensure that the post is vertical.
- 8 - Insert the bolts supplied. Tighten to hold the post securely. **DO NOT OVERTIGHTEN BOLTS.**

To Remove Post System:

For temporary installation and when spike is to be removed:

- 1 - Remove some of the ground from around the collar area.
- 2 - Insert a pry bar on 4x4 post under collar.
- 3 - Place another short 4x4 post under the pry bar or post.
- 4 - Push downward on the pry bar to safely release the spike from the ground. Spike may be reused in another application.